

Solidbase SK 1,8 mm - 68137

Solidbase SK 1,8 mm is a high density PU-mineral based compound, with a selfstick layer. Solidbase SK 1,8 mm is suitable for the installation of LVT dry back in domestic area's.

- Highly resistant to compressive loads and mechanical damage (> 400kPa)
- Strongly sound reduction
- Moisture barrier (sd >100m)
- Extremely suitable for underfloor heating and cooling

Installation method :	Floating installation with the selfstick layer up.
Direction of installation method	Always install the underlay in a 90 angle underneath the length of the floorcovering in order to avoid matching of seams in underlay and floorcovering.
General building inspection license:	Z-158.10-220 valid until 21-08-2023
Quietroom® label:	NA
Thickness:	1.8 mm / ± 0,18 mm - maximum tolerance 10%
Dimensions:	6,5m x 1m = ± 6,5m ²
Weight:	1450 gr/m ² / ± 145 gr/m ² - maximum tolerance 10%
Density:	905 kg/m ³ / ± 90 kg - maximum tolerance 10%
Material:	Middle Layer : PU / mineral compound Top Layer : Selfstick
Packing:	Material : recycled HDPE foil (no core) with insert sheet.

Technical information:

<i>Punctual conformity</i>	: Class PC1 -1 \geq mm < 2
<i>Compressive strenght</i> (test method: EN 826 + Annex a)	: Class CS3 - CS > 400kPa
<i>Caster chair test</i> (Test method: EN 985)	: Passed
<i>Impact sound reduction</i> (Test method: NA)	: $\Delta L_w = 17$ dB
<i>Thermal resistance</i> (Test method: NA)	: 0,06 togs - 0,006m ² K/W
<i>Fire retardency</i> (Test methode: EN ISO 9239-1:2010)	: Bfl-S1
<i>ASTM radial panel test</i> (Test methode: ASTM E 648-06)	: NA
<i>Russian requirements on fire safety</i> (Test methode: FZ-123)	: NA

Installation instructions:

- Let the floorcovering as well as the underpadding acclimatise for 24 hours in the original packing in the room to be installed.
- The best temperature for installation is 15-20°C. and a humidity of 50-70%.
- Make sure that the underfloor is absolutely dry and free of grit and dust.
- To cut the underpadding we recommend to use a trapezium blade.
- Underpadding can not prevent the natural shrinkage of Floorcovering. For that reason we strongly advise to leave a gap a 8-10mm allong all walls. Always follow the installation instructions of the floorcovering manufacturer.

Important:

In case the installation has not been done in accordance with the installation instructions, estillon can not be held responsible for any damage or claim as a result of an incorrect installation. In case of doubt always consult your supplier.

